Velotric Nomad 1 VELOTRIC

Quick Start Guide

We highly recommend you follow along with this video tutorial to assemble your eBike. Simply scan the QR code below.



Or visit: velotricbike.info/nomad1-2024

Contents

This guide will get your new eBike set up and ready to ride.

- What's in the Box
- Assembly and Installation
- Tire Pressure Check
- Battery & Charging
- Features and Test
- eBike Diagram

What's in the Box What's in the Box



Quick Start Guide




Owner's Manual



Tool Bag

- a Socket Wrench
- **b** Phillips Screwdriver
- 15mm/8mm Wrench
- d 10mm Wrench
- 6 6mm/5mm/4mm/3mm/2.5mm Allen Key










Left / Right Pedal

Front / Rear Reflector

Bell







Adapter & Charging Cable

Display

Front Light







Kickstand

Cap Nut Cover


Cable Binder


Kickstand

Front Wheel

Assembly and Installation


- Put on the cap nut cover.
- 2. Unscrew the bolts for the kickstand with the 5mm Allen key.
- Attach the kickstand and tighten the bolts.







- Open the quick release lever.
- Uscrew the quick release knob, and remove the quick release from the fork protective tray.
- **3.** Remove the spacer from the brake caliper.

Note The quick release is ONLY for this fork protection tray as a protection setup for transportation. You may trash it while unboxing. The quick release is NOT for Front Wheel assembly.







06

Front Wheel


Front Fender


Assembly and Installation

- 4. Insert the front wheel to the front fork. Seat the hub axle into the dropouts.
- 5. Tighten and secure the front cap nut with the socket wrench (Torque 30-35 Nm).
- 6. Ensure the rotor is wellpositioned (with gap) inside the brake caliper.


- Note 1. Torque can be measured by using a torque wrench.
 - 2. Be careful not to accidentally squeeze the brake levers before this step.
 - Otherwise you may cause misalignment on your hydraulic brakes.







- 1. Unscrew the bolts that affix the front fender to the fork top.
- 2. Attach the support rods to the fork legs with the 4mm Allen key.
- 3. Adjust the fender to your own preference. Ensure the wheel is centered and the gap between the fender and the wheel is clear. Fasten the bolts.





Handlebar

Handlebar


Assembly and Installation

- Flip the stem 180° and use a 5mm Allen key to tighten the screws on both side.
- 2. Use a 4mm Allen key to remove the handlebar stem cap.
- Insert the handlebar into the stem and prelock it (ensure that the handlebar is securely in place without any looseness).


Note Please make sure the stem and fork are in the correct direction.









- Adjust the handlebar to align with the crosshairs.
- Use a 4mm Allen key to tighten the handlebar stem cap in an X-pattern.
- Adjust the stem to make the handlebar perpendicular to the front wheel.







10


Assembly and Installation Adjustable Stem and Handlebar Adjustment


- Use a 5mm Allen key to loosen the locating screw at the bottom of the handlebar stem.
- Gently lift the handlebar and adjust it to the desired angle. Then tighten it. Torque: 14 Nm.
- Use a 4mm Allen key to loosen the four screws on the handlebar stem cap.


- Adjust the handlebar (ensure the straight section of the handlebar is parallel to the ground).
- 5. Use a 4mm Allen key to tighten the handlebar stem cap screws in an X-pattern to ensure even spacing above and below the stem cap. Torque range: 6-8 Nm.
- Use a 5mm Allen key to tighten the screw at the bottom of the handlebar stem.
















- Align the front light bracket with the mounting port on the handlebar stem cap and securely fasten the screw.
 Torque range: 2.5~5.5 Nm.
- 2. Align the power cable with the arrow and connect it.
- 3. Use a screwdriver and an open-end wrench to tighten the nut. Torque range: 2.5~5.5 Nm.


Note Before traveling at night, please check the front light to ensure it functions properly.






- Unscrew the bolts on the mounting brackets of the display.
- 2. Mount the display panel onto the handlebar and adjust it to an angle you can view easily on the seat in a riding position. Tighten the bolts with the 3mm Allen hey.
- Connect the display cables (marked green and blue) as shown below.
- Wrap the display wires together with the connected front light cable with the cable binder.







14


Bell and Front/Rear Reflector


Pedals


Assembly and Installation

- Unscrew the bolt on the bell mount and install the bell. Adjust the angle before tightening the bolt.
- Unscrew the bolt on the reflector mount and install the reflector. Adjust the angle before tightening the bolt.
- Attach the rear reflector to the seat post. Adjust the angle before tightening the bolt.


Note You can position the bell and reflector according to your preference.








- Identify each pedal by the sticker on the pedal axle: "L" indicates the left pedal and "R" indicates the right pedal.
- Install the right pedal. Carefully thread in the right pedal by hand, turning clockwise, as shown in the illustration below.
- Tighten the right pedal securely with a 15mm wrench.
- Install the left pedal. Carefully thread in the left pedal by hand, turning counter-clockwise, as shown in the illustration below.
- 5. Tighten the left pedal securely with a 15mm wrench.Torque range: 35 Nm to 40 Nm







Tire Pressure Check

Charge the Battery


- Check tire pressure by hand, and if it's easily compressible, it indicates low pressure and needs inflation.
- 2. Use an inflation pump equipped with an AV interface.
- Inflate the tire until it is no longer easily compressible (do not exceed the tire's maximum recommended pressure).
- 4. Follow the tire markings for the maximum recommended pressure.

Note Check tire pressure before every ride.





- Fit the battery into the down tube.
- Insert the key into the battery lock.
- 3. Press firmly to nest the battery and turn the key clockwise to lock it in place.







Battery & Charging

Charge the Battery


- The battery can be charged either in or out of the bike. Power off the bike before charging the battery in the bike.
- Make sure the battery is placed on a flat and clear surface. Plug the DC power cord (barrel connector) into the port.
- 3. Plug the adapter into the wall. The LED indicator will turn red.
- The indicator will turn green when the battery is fully charged. Unplug the adapter first before pulling out the cord from the battery.
- ▲ WARNING 1. Charge the battery in an environment from 50–86°F (10–30°C).
 - 2. The battery won't charge when it is over 113°F (45°C) or below 32°F (0°C). Let the battery adjust to room temperature for at least 1 hour before trying again.






Features and Test

- 1. Peel the protective film off the display screen.
- Hold the on/off button to power on/off the bike.
- Our system provides different levels of pedal assistance (1 = lowest, 5 = highest) so you can adapt the power output depending on your riding needs. Level 0 means no pedal assist.





Assist level 1

Eco Mode: Minimal power output for maximum battery efficiency.

Assist level 2

Tour Mode: Low power output for riding long distances.

Assist level 3

Normal Mode: Medium power output for city commuting.

Assist level 4

Sport Mode: Strong power output for active riding.

Assist level 5


Turbo Mode: Maximum power output for extreme riding.


Features and Test


eBike Diagram

When the display is on:

- 1. Hold the "+" button to turn on the **front light**. The display will dim automatically. Hold the "+" again to turn off the light, and the display lights up again.
- 2. Press "+/-" to shift the pedal assist level up or down.
- 3. Hold the "-" button to turn on Walk Mode at 2.9mph. Release the button to turn off Walk Mode.







Front Light

2 Handlebar

3 Stem

4 Saddle5 Seatpost

6 Seatpost Clamp

Motor

8 Cassette

9 Rear Derailleur

Chain

11 Crankset

Pedal

Battery


Brake Rotor

Brake Caliper

6 Tire

Suspension Fork

eBike Diagram



- Brake Lever
- B Remote
- O Display
- Be

- Throttle
- Shifter
- Grip

BECAUSE IT'S FUN.

VELOTRIC

Contact

Website: www.velotricbike.com E-mail: help@velotricbike.com