

INSTALLATION INSTRUCTION

1. Unscrew the two fixing bolts on both sides using a 5mm Allen wrench. Unscrew them until the rail of the saddle can fit between the 2 halves of the clamp.



2. Install the saddle by inserting the rail into the clamp from one side.



3. Press the saddle down until you hear the "click" noise.



4. Adjust the saddle so that it is centered and the top surface to be horizontal (recommended) as shown in the picture on the right.



5. Tighten the fixing bolt by a 5mm Allen wrench. Suggested tightening torque is 15-18Nm.

